

CIRCUIT OPERATION

Petrol Engine

For vehicles equipped with a manual transmission, cruise control can only be activated when the Cruise Control Switch (X115) is depressed, the transfer gear box is in Hi range, and the clutch pedal is not depressed. Also, the BeCM (Z238) will deactivate cruise control if the engine rpm rises above $5000 \pm 10\%$, due to the possibility of selecting gears manually without the use of the clutch.

For vehicles equipped with an automatic transmission, cruise control can only be activated when the Cruise Control Switch (X115) is depressed, the transfer gear box is in Hi range, and the transmission is in one of the forward gears.

With the Cruise Control Switch (X115) on, a ground signal is applied to C1279/Pin 14 of the BeCM (Z238). The BeCM (Z238) then supplies signal voltage via its Pin 18 to the Converter/Inverter (Z249), to Pin 8 of the Cruise Control ECU (Z121) and to the "Operation" bulb of the Cruise Control Switch (X115). The transfer gearbox Hi range status from the Transfer Gear Box ECU (Z256) is applied to C1287/Pin 3 of the BeCM (Z238). The X, Y, and Z switch status (PRND321 position information) from the gearbox position switch is applied to C1287/Pins 8, 9, and 18 of the BeCM (Z238). The clutch pedal position input is applied to C1279/Pin 4 and the engine speed input C1288/Pin 9 of the BeCM (Z238). When the transfer gearbox is in Hi range, a forward gear is selected and the Cruise Control Switch (X115) is on, the BeCM (Z238) supplies voltage via C1276/Pin 1 and the Brake Switch Vent Valve (X112) to the Cruise Control ECU (Z121) Pin 1, which then "knows" that cruise control can be operated.

When cruise control is activated and a cruise speed is set, the Cruise Control ECU (Z121) applies voltage through the OU wire and ground through the OR wire to operate the Cruise Control Vacuum Pump (M103) motor. The Cruise Control ECU (Z121) applies ground through the OK wire to close the normally open solenoid valve in the pump. The pump applies vacuum to the actuator.

SET/ACCEL

To set a cruise speed, the Cruise Control Switch (X115) must be on and vehicle speed must exceed 28 mph (45 km/h). When the SET/ACCEL Switch is depressed under these conditions, the

Converter/Inverter (Z249) is supplied with a ground signal. This signal is "converted" to a voltage signal and is transmitted via the SY wire to the Cruise Control ECU (Z121) terminal 4, causing the vacuum pump to operate. When the SET/ACCEL Switch is released, the signal is removed from terminal 4, signalling the ECU to set the speed.

RES/DECEL

When the RES/DECEL Switch is depressed, a signal is applied via the RY wire to terminal 2 of the Cruise Control ECU (Z121). This tells the ECU (Z121) to disengage the system and the vehicle slows down. When the switch is depressed a second time, the signal is again applied to the ECU (Z121) and the vehicle returns to the previously set speed.

Speed Input

Terminal 15 of the Cruise Control ECU (Z121) receives the Vehicle Speed output signal from the BeCM (Z238) through the Y or YR wire. The BeCM (Z238) receives the vehicle speed signal from the Anti-lock Brake System ECU (Z108). The signal is a pulsing voltage and its frequency changes with vehicle speed.

System Disable

The cruise control system can be disabled in one of four ways:

1. The Cruise Control Switch (X115) is put in the 0 position, removing the BeCM (Z238) power from the Cruise Control ECU (Z121) and vacuum pump, and erasing the set speed memory.
2. The RES/DECEL Switch is depressed, signalling the Cruise Control ECU (Z121) via the Inverter/Converter (Z249) to disengage the system.
3. The brake pedal is depressed and a vacuum valve in the Switch Vent Valve opens (X112). This vents vacuum to the actuator valve and releases the throttle.
4. The Voltage applied to the Cruise Control ECU (Z121) terminal 1 is interrupted, causing the Cruise Control ECU (Z121) to turn off the vacuum pump and de-energize the vacuum solenoid valve. This voltage path is interrupted when:
 - The brake pedal is depressed. With the brake pedal depressed, the Brake Switch Vent Valve (X112) moves to position 1 and the circuit is interrupted.
 - The transfer gear box is not in Hi range.
 - The vehicle speed does not exceed 28 mph (45 km/h).
 - The vehicle is not in a forward gear (P, R, or N) (Automatic Transmission).
 - The clutch pedal is depressed (Manual Transmission).
 - The engine rpm rises above $5000 \pm 10\%$ (Manual Transmission).

The BeCM (Z238), which monitors these signals, will then remove power from C1279/Pin 18.

Diesel Engine

For vehicles equipped with a manual transmission, cruise control can only be activated when the Cruise Control Switch (X115) is depressed and the clutch pedal is not depressed. The Diesel Engine Control Module (Z132) will not allow the engine to overspeed if a cruise control speed is requested that is beyond the capability of the engines speed range.

For vehicles equipped with an automatic transmission, cruise control can only be activated when the Cruise Control Switch (X115) is depressed, the transfer gear box is in Hi range, and the transmission is in one of the forward gears.

With the Cruise Control Switch (X115) on, a ground signal is applied to C1279/Pin 14 of the BeCM (Z238). The X, Y, and Z switch status (PRND321 position information) from the gearbox position switch is applied to C1287/Pins 8, 9, and 18 of the BeCM (Z238). The clutch pedal position input is applied to C1279/Pin 4 and the engine speed input is applied to C1288/Pin 9 of the BeCM (Z238). The BeCM (Z238) then supplies voltage, via its Pin 18 to the Inverter/Converter (Z249) and to the "Operation" bulb of the Cruise Control Switch (X115).

The Cruise Control Converter/Inverter Module (Z249) supplies the Engine Control Module (Z132) via its pin 4 with a voltage signal to "switch on" the cruise circuit. For the Diesel Engine, the Engine Control Module (Z132) controls the cruise circuit as the Cruise Control ECU (Z121) does for the Petrol Engine. The Engine Control Module (Z132) is also responsible for the acceleration/deceleration of the vehicle.

SET/ACCEL

To set a cruise speed, the Cruise Control Switch (X115) must be on and vehicle speed must exceed 28 mph (45 km/h). When the SET/ACCEL Switch is depressed under these conditions, the Inverter/Converter (Z249) is supplied with a ground signal. This signal is transmitted via the OY wire to the Engine Control Module (ECM) (Z132) causing the vehicle to accelerate. When the SET/ACCEL Switch is released, the signal is removed signalling the Engine Control Module (ECM) (Z132) to set the speed.

RES

When the RES Switch is depressed, a signal is applied to the ECM (Z132) and the vehicle will return to the previously set speed.

Speed Input

The BeCM (Z238) receives the vehicle speed signal from the Anti-lock Brake System ECU (Z108). The BeCM (Z238) then provides the vehicle speed signal to the Engine Control Module (ECM) (Z132). This signal is a pulsing voltage and its frequency changes with the vehicle speed.

System Disable

The cruise control system can be disabled in two ways:

1. The Cruise Control Switch (X115) is put in the 0 position, causing the BeCM (Z238) to remove power from the Engine Control Module (ECM) (Z132) and erasing the set speed memory.
2. The Voltage applied via the Inverter/Converter (Z249) to the Engine Control Module (ECM) (Z132) terminal 20 is interrupted, causing the Engine Control Module (ECM) (Z132) to disengage the system. This voltage path is interrupted when :
 - The brake pedal is depressed. The Engine Control Module (ECM) (Z132) has two Stop Lamp Switch (X168) inputs, each of opposite polarity. The ECM (Z132) compares the polarity states to determine when the brake pedal has been depressed.
 - The vehicle speed does not exceed 28mph (45 km/h).
 - The vehicle is not in a forward gear (P, R, or N) (Automatic Transmission).

- The clutch pedal is depressed (Manual Transmission).

The BeCM (Z238), which monitors these signals, will then remove power from C1279/Pin 18.

B5 CRUISE CONTROL


Road Test

CAUTION: DO NOT ENGAGE CRUISE CONTROL WHEN VEHICLE IS BEING USED IN LOW TRANSFER GEARS.


WARNING: The use of cruise control is not recommended on winding, snow covered or slippery roads, or in heavy traffic conditions where constant speed cannot be maintained.



1. Start the engine and depress the Cruise Control Switch (X115) to activate the cruise control system. Accelerate to approximately 30 mph (50 km/h) and press the SET/ACCEL Switch. Immediately release the switch and remove foot from the accelerator pedal. The vehicle should maintain the speed at which the SET/ACCEL Switch was pressed.
2. Press the SET/ACCEL Switch and hold at that position. The vehicle should accelerate smoothly until the switch is released. The vehicle should now maintain the new speed at which the SET/ACCEL Switch was released.
3. Press the RES/DECEL Switch while the vehicle is in the cruise control mode. The cruise control should disengage. Slow to approximately 35 mph (55km/h) and press the RES/DECEL Switch. Immediately release the switch and remove foot from the accelerator. The vehicle should smoothly accelerate to the previously set speed. Increase speed using the accelerator pedal. Releasing the pedal should return the vehicle to the previously set speed.
4. Depressing the brake pedal should immediately disengage the cruise control system and return the vehicle to driver's control at accelerator pedal. Press the RES/DECEL Switch and the vehicle should accelerate to the previously set speed without operation of the accelerator pedal.
5. Press the RES/DECEL Switch and allow the vehicle to decelerate to below 26 mph (42 km/h). Press the RES/DECEL Switch and remove foot from the accelerator pedal. The vehicle should smoothly adjust to the previously memorized speed.
6. Press the SET/ACCEL Switch below 28 mph (45km/h) and the cruise control system should remain disengaged. Accelerate the vehicle above 28 mph (45 km/h), press the RES/DECEL Switch and remove foot from the accelerator pedal. The vehicle should smoothly adjust to the previously memorized speed.
7. Pressing the Cruise Control Switch (X115) should immediately disengage the cruise control

system and erase the previously set speed from Cruise Control ECU (Z121)/Engine Control Module (ECM) (Z132) memory.






B5 CRUISE CONTROL (PETROL)







B5 CRUISE CONTROL (PETROL)





B5 CRUISE CONTROL (DIESEL)





TROUBLESHOOTING HINTS

5. If the interior lights operate but the cruise control switch light does not illuminate, check the bulb, B wire and RW wire. If the cruise control system operates but the cruise control switch light does not illuminate, check bulb and OW wire.
6. Inspect vacuum hoses for kinks and restrictions.
7. Inspect actuator linkage for restrictions and adjustment.
8. Check the following two input signals to the BeCM (Z238): Signal from Clutch Pedal Position Switch (X200) for vehicles equipped with a manual transmission, or the X, Y, and Z switch signals from the Gearbox Position Switch (X294) for vehicles equipped with an automatic transmission.
9. For vehicles equipped with a Petrol Engine, check the following input signal to the BeCM (Z238): Transfer box in Hi range signal from Transfer Gear Box ECU (Z256).
10. For vehicles equipped with a Diesel engine, check the Stop Lamp Switch (X168) inputs to the Engine Control Module (ECM) (Z132).
11. Note: For vehicles equipped with a manual transmission, cruise control can only be activated when the Cruise Control Switch (X115) is depressed, the transfer gear box is in Hi range (Petrol only), and the clutch pedal is not depressed. Also, the BeCM (Z238) will deactivate cruise control if the engine rpm rises above 5000 +/- 10 percent, due to the possibility of selecting manual without the use of the clutch (Petrol only). For vehicles equipped with an automatic transmission, cruise control can only be activated when the Cruise Control Switch (X115) is depressed, the transfer gear box is in Hi range (Petrol only), and the transmission is in one of the forward gears. The Transfer Gear Box ECU (Z256) provides the BeCM (Z238) with transfer gear box Hi range status. The Transfer Gear Box Position Switch (X294) provides the BeCM (Z238) with X, Y, Z switch status (PRND321 position information).

2. If the cruise control system does not operate correctly and the vehicle is equipped with a Diesel Engine, do Test E.

SYSTEM DIAGNOSIS

1. If the cruise control system does not operate correctly and the vehicle is equipped with a Petrol Engine, do Test A.

For petrol engine cars start here at Test "A", for Diesel engine cars start at test "E"

Test A

<p>1A</p> <p>CONDITIONS</p> <ul style="list-style-type: none">• Ignition Switch <i>Position: II</i>• Cruise Control Switch <i>On</i> <p>RESULTS</p> <p><i>Within 1.5V of battery voltage</i></p>	
--	--



GO TO TEST B




<p>2A</p> <p>CONDITIONS</p> <ul style="list-style-type: none">• Ignition Switch <i>Position: 0</i> <p>RESULTS</p> <p><i>Less than 1 ohm</i></p>	
--	--



PROBLEM CAUSE
- B Wire



B5 CRUISE CONTROL



PROBLEM CAUSE


- WY Wire
- B Wire
- Cruise Control Switch



PROBLEM CAUSE

- OW Wire
- Body Electrical Control Module (BECM)

Test B



PROBLEM CAUSE

- OW Wire



1B

2B

Z121
Cruise Control ECU

CONDITIONS

- Ignition Switch
Position: II
- Cruise Control Switch
On


RESULTS

- Steering Wheel Switches
RES/DECEL Switch

<i>On</i>	=	<i>BAT VOLT</i>	
<i>Off</i>	=	<i>0V</i>	



GO TO TEST C



3B

Z249
Cruise Control
Converter/Inverter
Module

CONDITIONS

- Ignition Switch
Position: 0

RESULTS

- Steering Wheel Switches
RES/DECEL Switch

<i>On</i>	=	<i>Less than 1 ohm</i>	
<i>Off</i>	=	<i>More than 10K ohms</i>	



PROBLEM CAUSE


- YR, W Wire
- B, PB Wire
- Steering Wheel Switches

PROBLEM CAUSE

- Cruise Control Converter/Inverter Module


- Rotary Coupler

Test C

1C	<p>CONDITIONS</p> <ul style="list-style-type: none"> • Ignition Switch <i>Position: II</i> • Cruise Control Switch <i>On</i> <p>RESULTS</p> <ul style="list-style-type: none"> • Steering Wheel Switches <i>SET/ACCEL Switch</i> <p><i>On</i> = BAT VOLT <i>Off</i> = 0 V</p>	 <p>Z121 Cruise Control ECU</p>
----	--	--



GO TO TEST D

2C	<p>CONDITIONS</p> <ul style="list-style-type: none"> • Ignition Switch <i>Position: 0</i> <p>RESULTS</p> <ul style="list-style-type: none"> • Steering Wheel Switches <i>SET/ACCEL Switch</i> <p><i>On</i> = Less than 1 ohm <i>Off</i> = More than 10K ohms</p>	 <p>Z249 Cruise Control Converter/Inverter Module</p>
----	--	--



PROBLEM CAUSE

- YS,R Wire
- Rotary Coupler



PROBLEM CAUSE

- Cruise Control Converter/Inverter Module

- Steering Wheel Switches

Test D

1D	<p>CONDITIONS</p> <ul style="list-style-type: none"> ● Ignition Switch <i>Position: II</i> <p>RESULTS</p> <ul style="list-style-type: none"> ● Brake Pedal <table style="margin-left: 20px;"> <tr> <td><i>Depressed</i></td> <td>=</td> <td>BAT VOLT</td> </tr> <tr> <td><i>Released</i></td> <td>=</td> <td>0 V</td> </tr> </table> 	<i>Depressed</i>	=	BAT VOLT	<i>Released</i>	=	0 V	
<i>Depressed</i>	=	BAT VOLT						
<i>Released</i>	=	0 V						



- PROBLEM CAUSE**
- GP Wire
 - W Wire
 - Stop Lamp Switch




2D	<p>CONDITIONS</p> <ul style="list-style-type: none"> ● Ignition Switch <i>Position: II</i> ● Cruise Control Switch <i>On</i> ● Transfer Box <i>Hi Range</i> ● Gear Selector <i>Forward Gear</i> <p>RESULTS</p> <ul style="list-style-type: none"> ● Brake Pedal <table style="margin-left: 20px;"> <tr> <td><i>Depressed</i></td> <td>=</td> <td>0 V</td> </tr> <tr> <td><i>Released</i></td> <td>=</td> <td>BAT VOLT</td> </tr> </table> 	<i>Depressed</i>	=	0 V	<i>Released</i>	=	BAT VOLT	
<i>Depressed</i>	=	0 V						
<i>Released</i>	=	BAT VOLT						



- PROBLEM CAUSE**
- OR, ON Wire
 - Brake Switch Vent Valve
 - Body Electrical Control Module (BECM)




B5 CRUISE CONTROL



PROBLEM CAUSE


- Y, YR Wire
- Body Electrical Control Module (BECM)



PROBLEM CAUSE

- OU, OR Wire
- Cruise Control Vacuum Pump





PROBLEM CAUSE


- OK Wire
- Cruise Control Vacuum Pump



PROBLEM CAUSE

- Cruise Control ECU


Test E




GO TO TEST F

B5 CRUISE CONTROL

1E



PROBLEM CAUSE
- B Wire




PROBLEM CAUSE
- WY Wire
- B Wire
- Cruise Control Switch





PROBLEM CAUSE
- OW Wire
- Body Electrical Control
Module (BECM)

Test F




OK PROBLEM CAUSE

- GB Wire
- Stop Lamp Switch




OK PROBLEM CAUSE

- YP Wire
- Stop Lamp Switch




B5 CRUISE CONTROL



PROBLEM CAUSE

- Y, YG Wire
- Body Electrical Control Module (BECM)



PROBLEM CAUSE

- OY, YO Wire



4F

5F

CONDITIONS

- Ignition Switch
Position: 0

RESULTS

- Steering Wheel Switches
RES/DECEL Switch

On	= Less than 1 ohm	
Off	= More than 10K ohms	

Z249
Cruise Control
Converter/Inverter
Module



PROBLEM CAUSE

- YR, W Wire
- B, PB Wire
- Rotary Coupler



- Steering Wheel Switches

6F

CONDITIONS

- Ignition Switch
Position: 0

RESULTS

- Steering Wheel Switches
SET/ACCEL Switch

On	= Less than 1 ohm	
Off	= More than 10K ohms	

Z249
Cruise Control
Converter/Inverter
Module



PROBLEM CAUSE

- YS, R Wire
- Rotary Coupler



PROBLEM CAUSE

- Cruise Control Converter/Inverter Module

- Steering Wheel Switches

- Body Electrical Control Module (BECM)

