

result in personal injury.

- NOTE: When the coolant bleed is complete and prior to installing the expansion tank cap, top-up the expansion tank to 30mm above the maximum level.

Switch the engine off.

- Remove the coolant expansion cap, allow the level to settle and top-up so that the level is 30mm above the upper level.
- Allow the engine to cool.

15. Clean any spilt coolant from the vehicle.

16. Check and top-up the coolant if required.