

3. Feed cable through valance.
4. Fit grommet between cable and valance.
5. Fit cable to securing clip on underside of hood platform.
6. Fit cable to lock and tighten clamping bolt.
7. Check operation of release cable and hood lock and adjust if necessary.
8. Fit grille and tighten screws.
9. Close hood.