



place it all together..
make the spring unit ready shown in the next picture.
Put the cable through is before screwing the nipple on the wire!!

