



E79902

Item	Part Number	Description
1	-	Bolt (1 off)
2	-	CMP sensor
3	-	LH cylinder head camshaft
4	-	O-ring seal
5	-	Cylinder head

The CMP sensor locates through a hole in a flange on the rear RH side of the LH cylinder head. The rear of the inlet camshaft incorporates a trigger wheel, which is used in conjunction with the sensor to measure engine position.

For additional information, refer to: [Electronic Engine Controls](#) (303-14C Electronic Engine Controls - TDV8 3.6L Diesel, Description and Operation).

Exhaust Gas Recirculation (EGR) Valve Assembly