

142670 miles 000.0 + 72°F
HDC INACTIVE

P

BRAKE ABS





142670 miles 000.0 + 72°F
AIR SUSP. INACTIVE

P

BRAKE ABS

PROG

DSC





MPH km/h

r/min x 1000

2670

miles 000.0

+ 72°F

P

AIR SUSP. INACTIVE

BRAKE ABS





2670 miles 000.0 + 72°F
HDC INACTIVE

P

BRAKE ABS
BRAKE ABS

Read Faults

Clear Faults

Close

You Should See Alternating Tx and Rx Signals.
Retrieving ECU Fault Information

.....

Air Suspension System Fault Reading Complete...
Fault Report Completed.

	Description
	CAN bus Fault.

Open

Read Faults

Clear Faults

Close

You Should See Alternating Tx and Rx Signals.


Retrieving ECU Fault Information

!!!!!!!

Air Suspension System Fault Reading Complete...

Fault Report Completed.

	Description
	CAN bus Fault.
*	



Open Read Faults Clear Faults Close

Sending Air Suspension Module Communications.
You Should See Alternating Tx and Rx Signals.
Clearing ECU Fault Information
!!!
Air Suspension System Fault Codes Cleared.

	Description
▶	CAN bus Fault
✱	