


Engine Cooling - ID4 2.2L Diesel - Engine Cooling

Description and Operation

COMPONENT LOCATION



E138698

Item	Part Number	Description
1	-	Cooling fan
2	-	Outlet connector
3	-	Radiator upper hose
4	-	Coolant pump
5	-	Distribution manifold
6	-	Bleed screw
7	-	Heater return connection
8	-	Expansion tank
9	-	Heater feed connection
10	-	EGR (exhaust gas recirculation) cooler