

Module-Driver seat

ROW 2 SQUAB MOTOR RECLINE

ROW 2 SQUAB MOTOR INCLINE

ROW 2 SQUAB MOTOR SENSE

GND B

ROW 3 RELEASE SENSE

ROW 3 LATCH

ROW 3 RELEASE

ROW 2 SEAT POS SW1

ROW 2 SEAT POS SW2


ROW 2 ACTUATOR SENSE

ROW 2 ATUATOR LATCH


ROW 2 ACTUATOR RELEASE

ROW 2 MID HEADREST SOLENOID


ROW 2 MID HEADREST GND




Motor-Seat-Backrest-Recline-Rear-Right




Motor-Seat latch release-Third row-Right



Switch-Seat position



Actuator-Seat release



Motor-Head restraint-RH

