




21. Remove the 4 bolts.



22. Install the special tool.




23. Install the special tool.



24. NOTE: Raise the transmission jack.

Remove the right-hand transfer case mount.

- Remove the 4 bolts.
- Remove the nut.



25. With assistance, remove the transfer case.