



Dougs Landrover wiring 2010 Sherpa diesel in ex petrol Series 3 88 " with extra's

- 1 Starter Motor
- 2 Solenoid starter motor
- 3 Switch for horn
- 4 Horn
- 5 Inspection lamp sockets
- 6 Instrument panel lamps
- 7 Instrument panel lamps
- 8 Fog light switch
- 9 Tail Lamp LH
- 10 Tail Lamp RH
- 11 Side Lamp LH
- 12 Side Lamp RH
- 13 Headlamp LH dip beam
- 14 Headlamp RH dip beam
- 15 Warning lamp headlamp Main beam
- 16 Headlamp LH Main beam
- 17 Headlamp RH Main beam
- 18 Direction indicator lamp Rear RH
- 19 Direction indicator lamp Front RH
- 21 Direction indicator lamp Front LH
- 22 Direction indicator lamp Rear LH
- 23 Battery
- 24 Diesel stoip solenoid
- 25 Switch Headlamp flash / dip / Main

- 26 Warning lamp indicator RH
- 27 Warning lamp indicator RH
- 28 Fuses 1-4 25A
- 29 Indicator Flasher unit
- 30 Indicator switch
- 31 Alternator Lucas 16ACR
- 32 Warning lamp ignition
- 33
- 34 Warning light oil pressure
- 35 Warning light low fuel
- 36 Voltage stabiliser for temp & fuel
- 37 Switch stop lamp
- 38 Switch windscreen wiper
- 39 Switch screen wash on back of 38
- 40 Switch low fuel
- 41 Fuel gauge
- 42 Water temp gauge original
- 43 Wiper motor
- 44 Wash motor
- 45 Switch oil pressure
- 46 Fuel tank sender
- 47 Water temp sender
- 48 Stop Lamp LH
- 49 Stop lamp RH
- 50 Screen wash pump

- 51 Interior light
- 52 Rad Electric fan switch
- 53 Rad Electric fan
- 54 Rad Electric fan Relay LH on slam panel
- 55 Temp switch for Rad Electric fan
- 56 Heater switch two speed
- 57 Heater fan
- 58 Rear wiper motor
- 59 Rear washer motor
- 60 Reverse light switch on Gearbox
- 61 Reverse light
- 62 Reverse light dash indicator
- 63 Extra temp sender front engine block
- 64 Extra temp gauge
- 65 Fog Light
- 66 Fog light Dash indicator lamp
- 67 Glow plug relay on bulkhead.
- 68 Glow Plugs
- 69 Aux lighter socket under passenger seat
- 70 Radio
- 71 Relay Main Beam middle on slam panel
- 72 Relay Dip Beam RH on slam panel
- 73 Temp and oil pressure gauge lights
- 74 Rear wash wipe switch.
- 75 Intermittent wipe switch
- 76 Intermittent wipe relay in dash.
- 77 Rear window heater relay front under seat
- 78 Rear window heater switch

Fuses in passenger seat box

- F1 Interior light 5A
 F2 Head lights and rad fan supply to relays on slam panel 30A
 F3 Glow plugs 45A
 F4 Aux lighter socket 20A
 F6 Rear wiper motor relay and wash pump
 F7 Rear wiper motor 10A
 F8 Rear door heated window 10A
 F9 Spare

F5 Inline fuse to radio 5A back of radio.

Original fuses

- Top 25A
 2nd 25A
 3rd 25A
 4th 25A

B	Black	R	Red
G	Green	U	Blue
L	Light	W	White
N	Brown	Y	Yellow
P	Purple		

The last letter of a colour code denotes the tracer colour

