

INSPECTION 1

TDV8 DERIVATIVES from 11MY

Invoice No. _____

Registration Date _____

Registration No. _____

Odometer Reading _____

VIN _____

Adjust/Lubricate/Renew - Labour cost included in scheduled times except items marked *.

Check - After checking procedure, cleaning, repairing or replacing is subject to extra labour and material cost.

VEHICLE INTERIOR	✓/X
1. Reset the Service Interval Indicator.	
2. Check operation of all lamps, horns and warning indicators.	
3. Check operation of front/rear wipers and washers and condition of wiper blades.	
4. Select the LOW range gears and drive the vehicle 3 to 4 vehicle lengths then re-select HIGH range gears.	
5. Check condition and security of seats and seat belts.	
6. Replace climate controlled seat cushion motor filters. (where fitted)	
7. Replace airbag SRS and seat belt pre-tensioners*. (every 15 years)	

VEHICLE EXTERIOR	✓/X
8. Check tyres pressures, and adjust if necessary.	
<div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; width: 100px; height: 30px;"></div> <div style="border: 1px solid black; width: 100px; height: 30px;"></div> <div style="border: 1px solid black; width: 100px; height: 30px;"></div> </div>	
9. Remove road wheels.	
10. Check brake pads for wear, calipers for leaks and discs for condition.	
11. Grease wheel centre surfaces.	
12. Check tyres for damage, condition and tread depth.	
<div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; width: 100px; height: 30px;"></div> <div style="border: 1px solid black; width: 100px; height: 30px;"></div> <div style="border: 1px solid black; width: 100px; height: 30px;"></div> </div>	
13. Refit road wheels to opposite sides of the same axle. (Ref. Bulletin 0032 - Suspension) - NOT vehicles fitted with uni-directional tyres	
14. Apply lubricant to top edge of door seals.	

UNDER BONNET	✓/X
15. Check battery condition.	
16. Check/top up battery electrolyte level.	
17. Replace pollen filter.	
18. Replace air cleaner element.	
19. Check condition of ancillary drive belt.	
20. Check/top up brake, PAS and screen washer fluid levels.	
21. Replace brake fluid every 3 years* .	
22. Check coolant level, change coolant every 10 years* .	
23. Replace fuel filter element.	

UNDER VEHICLE	✓/X
24. Replace engine oil and filter.	
25. Drain fuel filter water separator.	



RANGE ROVER

UNDER VEHICLE	✓/X
26. Check all powertrain components for fluid leaks.	
27. Check steering components for security and wear.	
28. Check suspension fixings.	
29. Check brake, fuel, PAS and suspension pipes and connections for security, leakage, corrosion and possible chafing.	
30. Check the adjustment of the electric park brake.	
31. Renew locking differential fluid every 5 years/75,000 miles* - 3.6L	
32. Replace transfer case fluid every 5 years/75,000 miles* - 3.6L	
33. Replace transfer case fluid every 5 years/80,000 miles* - 4.4L	
34. Renew locking differential fluid every 5 years/80,000 miles* - 4.4L	
35. Renew front and rear axle fluid every 10 years* .	
36. Replace automatic transmission fluid and filter every 9 years/144,000 miles* - 4.4L	
37. Replace automatic transmission fluid and filter every 10 years/150,000 miles* - 3.6L	

ANTI - CORROSION CHECK LIST	✓/X
38. Visually check the underbody sealer for damage (pay particular attention to areas of apparent repair).	
Using an inspection lamp, check for corrosion/damaged underbody sealer on:	
39. Sills and wheel arches.	
40. Main floor.	
41. Subframe.	
42. Areas adjacent to suspension mounting and fuel tank fixings.	
NOTE: Small blisters in the PVC underbody sealer are acceptable providing they do not reveal bare metal.	
43. Inspect an report, exterior paintwork for damage and body panels for corrosion (pay particular attention to areas of apparent repair).	
Visually check for evidence of damage and corrosion on all paint finished areas particularly:	
44. Front edge of bonnet.	
45. Lower body and door panels.	
46. Check visible flanges in engine and luggage compartments.	
47. Check clinched edges and hinge areas of bonnet.	
48. Remove interior vehicle protection kit.	
Please tick one of the following boxes.	
49. Remedial work required, list below.	
50. NO remedial work required.	

ROAD TEST	✓/X
51. Road test vehicle.	

