

INSPECTION 1

ALL DERIVATIVES

Invoice No.
 Registration Date
 Registration No.
 Odometer Reading
 VIN



RANGE ROVER

--

Adjust/Lubricate/Renew - Labour cost included in scheduled times except items marked *.

Check - After checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost.

✓ = OK

✗ = not OK

VEHICLE INTERIOR

1	Reset the Service Interval Indicator.	
2	Check operation of parking brake.	
3	Check operation of all lamps, horns and warning indicators.	
4	Check operation of front/rear wipers and washers and condition of wiper blades.	
5	Check condition and security of seats and seat belts.	
6	Replace airbag SRS and seat belt pre-tensioners* (every 15 years)	

VEHICLE EXTERIOR

7	Remove road wheels.							
8	Check brake pads for wear, calipers for leaks and discs for condition.							
9	Grease wheel centre surfaces.							
10	Check tyre pressures, and adjust if necessary.							
	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> </tr> <tr> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> </tr> </table>							
11	Check tyres for damage, condition and tread depth.							
	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> </tr> <tr> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> <td style="border: 1px solid black; width: 30%; height: 20px;"></td> </tr> </table>							
12	Replace road wheels.							
13	Apply silicone spray to top edge of door seals.							

UNDER BONNET

14	Check battery condition.	
15	Replace pollen filter.	
16	Check condition of ancillary drive belt.	
17	Check/top up brake, PAS and screen washer fluid levels.	
18	Replace brake fluid every 3 years*.	
19	Check coolant level, change coolant every 4 years*.	

UNDER VEHICLE

20	Replace engine oil and filter.	
----	--------------------------------	--

UNDER VEHICLE

21	Check all powertrain components for fluid leaks.	
22	Check steering components for security and wear.	
23	Check suspension fixings.	
24	Check brake, fuel, PAS and suspension pipes and connections for security, leakage, corrosion and possible chafing.	

ANTI - CORROSION CHECK LIST

25	Visually check the underbody sealer for damage (pay particular attention to areas of apparent repair).	
	Using an inspection lamp, check for corrosion/damaged underbody sealer on:	
26	Sills and wheel arches.	
27	Main floor.	
28	Subframe.	
29	Areas adjacent to suspension mounting and fuel tank fixings.	
	NOTE: Small blisters in the PVC underbody sealer are acceptable providing they do not reveal bare metal.	
30	Inspect an report, exterior paintwork for damage and body panels for corrosion (pay particular attention to areas of apparent repair).	
	Visually check for evidence of damage and corrosion on all paint finished areas particularly:	
31	Front edge of bonnet.	
32	Lower body and door panels.	
33	Check visible flanges in engine and luggage compartments.	
34	Check clinched edges and hinge areas of bonnet.	
35	Remove interior vehicle protection kit.	
	Please tick one of the following boxes.	
36	Remedial work required, list below.	
37	NO remedial work required.	

ROAD TEST

38	Road test vehicle.	
39	Endorse service record.	
40	Report any unusual features of the vehicle condition and additional work required.	

